

Heating

- To adjust the temperature for the entire house, please use the thermostat dial in the entrance hallway (located between the living room and twin bedroom door).
- Adjust the dial to the desired temperature and press to confirm your selection.
- Use the thermostatic handles on radiators to increase/decrease temperature in individual rooms.
- The upstairs bathroom has electrical underfloor heating. Panel located in the bathroom.