

Heating

- To adjust the temperature for the entire house, please use the thermostat dial in the entrance hallway (between the living room door and the stairs). Adjust the dial to the desired temperature and press to confirm your selection.
- Use the thermostatic handles on radiators to increase/decrease temperature in individual rooms.
- The bathroom has electrical underfloor heating. The control panel is located outside the bathroom.